

Όνομα Προϊόντος	Clip
Κωδικός	310
Οδηγίες χρήσης	<p>Οδηγίες χρήσης:</p> <ul style="list-style-type: none"> ▪ Όταν χρησιμοποιείτε το Clip με πιπίλα MAM ή άλλη πιπίλα με κουμπί στήριξης, περάστε τον διαφανή δακτύλιο γύρω από το κουμπί. ▪ Όταν το χρησιμοποιείτε με πιπίλα με κρίκο περάστε τον διαφανή δακτύλιο γύρω από τον κρίκο της πιπίλας ή περάστε την κορδέλα απευθείας στον κρίκο και συνδέστε την άκρη της στην επιφάνεια του κριτς-κρατς. ▪ Χωρίς τον δακτύλιο το Clip εκτός από πιπίλες μπορεί να στηρίζει και πολυκρίκους, μικρά παιχνιδάκια και άλλα παρόμοια είδη. ▪ Το στήριγμα του Clip ανοίγει μετακινώντας τον σφικτήρα του προς την κατεύθυνση της κορδέλας και κλείνει μετακινώντας τον προς το στρογγυλεμένο άκρο του. ▪ Στηρίξτε το Clip αποκλειστικά στα ρουχαλάκια του μωρού. ▪ Το στήριγμα του Clip πρέπει να αποθηκεύεται και να πλένεται ανοιχτό, για να μην αποδυναμώνεται η λειτουργία του. Μην αποθηκεύετε το Clip με κλειστό στήριγμα. ▪ Πλένετε τακτικά το Clip με ζεστό νερό και ήπιο απορρυπαντικό. Ξεπλένετε προσεκτικά. ΜΗΝ ΤΟ ΒΡΑΖΕΤΕ και μην το αποστειρώνετε με ατμό ή σε φούρνο μικροκυμάτων. ▪ Μην χρησιμοποιείτε ισχυρά καθαριστικά διότι ενδέχεται να καταστρέψουν το προϊόν. <p>Για την ασφάλεια του παιδιού σας ΠΡΟΕΙΔΟΠΟΙΗΣΗ!</p> <ul style="list-style-type: none"> ▪ Ελέγχετε το προϊόν πριν από κάθε χρήση και αντικαταστήστε το με την πρώτη ένδειξη φθοράς. ▪ Ποτέ μην επιμηκύνετε του Clip! ▪ Ποτέ μην προσαρτάτε το Clip σε κορδόνι, ζώνη, τιράντα ή σε κάποιο λυτό κομμάτι του ρούχου του μωρού. Κίνδυνος στραγγαλισμού. ▪ Σας συστήνουμε να μην χρησιμοποιείτε το Clip όταν το μωράκι κοιμάται. ▪ Σιγουρευτείτε ότι και οι δύο άκρες του είναι καλά στερεωμένες πριν αφήσετε το μωρό σας χωρίς επιτήρηση. ▪ Το Clip δεν είναι παιχνίδι και δεν πρέπει να χρησιμοποιείται σαν πολυκρίκος οδοντοφυΐας ή παιχνιδάκι. <p>Instructions for use:</p> <ul style="list-style-type: none"> ▪ When used with a MAM or other button soother, press the ring over the button of the soother. ▪ When used with a soother with handle, put the transparent ring over the whole handle of the soother, or attach the ribbon directly to the soother handle, using the hook & loop fastener. ▪ The hook & loop fastener securely holds not only soothers but also teethers, small toys and much more. ▪ The clip fastener is opened by moving the slider towards the leash and closed by clicking the slider towards the rounded end. ▪ The clip should only be attached to garments. ▪ The clip fastener should always be stored and cleaned in the open position to avoid the clip spring losing its strength. Do not store in the closed position.



	<ul style="list-style-type: none">▪ Regularly clean the clip with warm water and mild cleaning agent. Rinse thoroughly. DO NOT BOIL, steam or microwave sterilise.▪ Do not use solvents or abrasive cleaning agents as these could damage the product. <p>For your child's safety WARNING!</p> <ul style="list-style-type: none">▪ Before each use check carefully. Throw away at the first sign of damage or weakness.▪ Never lengthen the soother holder!▪ Never attach to cords, ribbons, laces or loose parts of clothing. The child may be strangled.▪ The use of a clip when baby is sleeping or in bed, crib or cot is not recommended.▪ Ensure both ends of the clip are fastened before leaving your child unattended.▪ The clip should not be used as a teether or toy.
Λοιπές πληροφορίες	<p>Το προϊόν πληροί τις προδιαγραφές της Ευρωπαϊκής Οδηγίας EN 12586: 2007 Κατασκευάζεται στην Ευρώπη.</p> <p>This product meets the requirements of EN 12586: 2007. Made in Europe.</p>