

Όνομα Προϊόντος	Clip it! & Cover
Κωδικός	335
Οδηγίες χρήσης	<p>Οδηγίες χρήσης:</p> <ul style="list-style-type: none"> ▪ Όταν χρησιμοποιείτε το Clip it! με πιπίλα MAM ή άλλη πιπίλα με κουμπί στήριξης, περάστε τον διαφανή δακτύλιο γύρω από το κουμπί της. ▪ Όταν το χρησιμοποιείτε με πιπίλα με κρίκο περάστε το κορδόνι του (αφού αφαιρέσετε τον δακτύλιο) γύρω από τον κρίκο της πιπίλας. ▪ Το κορδόνι εκτός από πιπίλες με κρίκο μπορεί να στηρίξει πολυκρίκους, μικρά παιχνιδάκια και άλλα παρόμοια είδη. ▪ Το στήριγμα του Clip it! ανοίγει μετακινώντας τον σφικτήρα του προς την κατεύθυνση της κορδέλας και κλείνει μετακινώντας τον προς το στρογγυλεμένο άκρο του. ▪ Στηρίξτε το Clip it! αποκλειστικά στα ρουχαλάκια του μωρού. ▪ Το στήριγμα του Clip it! πρέπει να αποθηκεύεται και να πλένεται ανοιχτό, για να μην αποδυναμώνεται η λειτουργία του. Μην αποθηκεύετε το Clip it! με κλειστό στήριγμα. ▪ Πλένετε τακτικά το προϊόν με ζεστό νερό και ήπιο απορρυπαντικό. Ξεπλένετε προσεκτικά. ΜΗΝ ΤΟ ΒΡΑΖΕΤΕ και μην το αποστειρώνετε με ατμό ή σε φούρνο μικροκυμάτων. ▪ Μην χρησιμοποιείτε ισχυρά καθαριστικά γιατί ενδέχεται να το καταστρέψουν. ▪ Πλένετε το προστατευτικό της θηλής όπως το Clip it! ή βάλτε το στο πλυντήριο πιάτων. Το προστατευτικό θηλής μπορεί να αποστειρωθεί με βρασμό (5 λεπτά), με ατμό ή σε αποστειρωτή φούρνου μικροκυμάτων. Αφαιρέστε το προστατευτικό θηλής από την κορδέλα πριν το αποστειρώσετε ή το βάλτε στο πλυντήριο πιάτων. ▪ Τοποθετήστε το προστατευτικό θηλής γύρω από τη θηλή της πιπίλας και κλείστε το. Ασφαλίζει σωστά όταν κουμπώσει ακριβώς στην άκρη του λαιμού της θηλής στη βάση της ασπίδας. ▪ Όταν το προστατευτικό είναι συνδεδεμένο με τη θηλή της πιπίλας ανοίξτε το στρίβοντάς το. Όταν δεν είναι συνδεδεμένο με πιπίλα ανοίξτε το πιέζοντας με το δάχτυλό σας το άνοιγμά του. ▪ Για να βρίσκετε εύκολα το προστατευτικό θηλής, συνδέστε το στον ρυθμιστή μήκους. ▪ Ο ρυθμιστής μήκους χρησιμοποιείται για να επιμηκύνει ή να κοντύνει την κορδέλα με απλή μετακίνησή του κατά μήκος της κορδέλας. ▪ Μην ανησυχήσετε εάν το χεράκι ή το δαχτυλάκι του μωρού σκαλώσει στο κορδόνι της κορδέλας. Απομακρύνετε το όσο το δυνατόν πιο μαλακά. Το υφασμάτινο κορδονάκι δεν θα προκαλέσει κανέναν τραυματισμό. <p>Για την ασφάλεια του παιδιού σας ΠΡΟΕΙΔΟΠΟΙΗΣΗ!</p> <ul style="list-style-type: none"> ▪ Ελέγχετε το προϊόν πριν από κάθε χρήση και αντικαταστήστε το με την πρώτη ένδειξη φθοράς. ▪ Ποτέ μην επιμηκύνετε το Clip it! ▪ Ποτέ μην το προσαρτάτε σε κορδόνι, ζώνη, τιράντα ή σε κάποιο λυτό κομμάτι του ρούχου του μωρού. Κίνδυνος στραγγαλισμού. ▪ Σας συστήνουμε να μην χρησιμοποιείτε την κορδέλα στήριξης όταν το μωράκι κοιμάται. ▪ Σιγουρευτείτε ότι και οι δύο άκρες του είναι καλά στερεωμένες πριν

αφήσετε το μωρό σας χωρίς επιτήρηση.

- Το Clip it! δεν είναι παιχνίδι και δεν πρέπει να χρησιμοποιείται σαν πολυκρίκος οδοντοφυΐας ή παιχνιδάκι.
- Διατηρείτε το προστατευτικό της θηλής μακριά από τα παιδιά προς αποφυγή πνιγμού.

Instructions for use:

- When used with a MAM or other button soother, press the ring (which is attached to the flexible loop) over the button of the soother.
- When used with a soother with handle, attach the flexible loop directly to the handle of the soother.
- The flexible loop securely holds not only soothers but also teethers, small toys and much more.
- The clip fastener is opened by moving the slider towards the leash and closed by clicking the slider towards the rounded end.
- The clip should only be attached to garments.
- The clip fastener should always be stored and cleaned in the open position to avoid the clip spring losing its strength. Do not store in the closed position.
- Regularly clean the clip and the flexible ring with warm water and mild cleaning agent. Rinse thoroughly. DO NOT BOIL, steam or microwave sterilise.
- Do not use solvents or abrasive cleaning agents as these could damage the product.
- Clean the teat cover in the same way as the clip or clean in the dishwasher. The teat cover can also be sterilised by boiling (5 min.), or in a microwave steriliser or steam steriliser. Remove the teat cover from the leash before sterilising or dishwashing.
- Position the teat cover directly over the soother teat and close. The teat cover is securely attached when it snaps together around the base of the teat, directly behind the soother shield.
- Open the teat cover by twisting it when clipped onto the soother teat. When not clipped onto the soother teat, open it by pushing your finger inside the opening.
- To keep teat cover at hand clip it onto the length controller.
- The length controller can be used to lengthen or shorten the clip leash by simply pulling it up or down along the leash.
- Do not worry if your child's arm, wrist or finger gets stuck in the loop of the strap. Remove as gently as possible. The textile loop will not cause any harm.

For your child's safety

WARNING!

- Before each use check carefully. Throw away at the first sign of damage or weakness.
- Never lengthen the soother holder!
- Never attach to cords, ribbons, laces or loose parts of clothing. The child may be strangled.
- The use of a clip when baby is sleeping or in bed, crib or cot is not recommended.
- Ensure both ends of the clip are fastened before leaving your child unattended.
- The clip should not be used as a teether or toy.
- Keep the removable teat protector away from children to avoid suffocation.



Λοιπές πληροφορίες	Το Clip it! πληροί τις προδιαγραφές της Ευρωπαϊκής Οδηγίας EN 12586: 2007 Κατασκευάζεται στην Ευρώπη. The clip meets the requirements of EN 12586: 2007. Made in Europe.
---------------------------	---